

CARE & STORAGE

Keep your device ready for use

AFTER EACH SESSION

Turn the device off before removing or disconnecting electrodes. Peel pads gently from an edge; do not pull on wires. Replace the protective liners on reusable adhesive pads.

CLEAN & PROTECT

Switch off and disconnect power before cleaning. Wipe the housing with a soft, lightly damp cloth and dry. Do not immerse, spray, or allow liquid into connectors. Follow the supplied pad care directions; do not use solvents or scrub the gel.

STORE SAFELY

Keep the unit and pads in a cool, dry place away from sunlight and heat. Keep small parts and batteries away from children and pets. Replace pads that are damaged, dry, dirty, or no longer adhere fully.

PRODUCT SUPPORT

Care you can depend on

JS-1 AT A GLANCE

Product: Transcutaneous Electrical Joint Stimulation Device
SKU: JS-1
Application: External electrical stimulation through skin-contact electrodes.
Use only compatible electrodes and accessories.

CONTACT US

Distributed by:
United Yoram Inc.
Brooklyn, NY 11236

drfranklyns.com
support@drfranklyns.com
Instagram: @drfranklyns



SCAN FOR PRODUCT DETAILS



HEALTH | SUPPORT | RECOVERY

JOINT STIMULATION DEVICE

Transcutaneous Electrical Stimulation



USER GUIDE | SKU JS-1

Read all instructions before use.
Keep this guide for future reference.

PURPOSE & SAFETY

Read before using your device

HOW IT WORKS

Electrical pulses pass through electrodes placed on the skin to stimulate underlying nerves. This type of stimulation may help temporarily manage discomfort. Response varies; it does not diagnose or cure the cause of pain.

DO NOT USE

Do not use with a pacemaker, implanted defibrillator, or other implanted electronic device. Do not use on broken, infected, inflamed, numb, or irritated skin. Do not use while sleeping, driving, bathing, or operating machinery.

ASK A CLINICIAN FIRST

Seek medical advice before use if pregnant, you have epilepsy, heart disease, cancer, impaired circulation or sensation, unexplained pain, or a recent injury or surgery. Use around a surgical site only if your clinician approves. Keep out of reach of children.

GETTING STARTED

Prepare • Place • Begin gently

1 PREPARE

Inspect the device, connectors, and pads for damage. Power the unit only as marked on its label. For rechargeable components, disconnect the charging cable before applying stimulation. Clean and dry the intended skin area.

2 POSITION ELECTRODES

With the unit off, attach compatible pads and any supplied connections securely. Remove pad liners and apply the entire conductive surface to bare skin. Ask your clinician for placement suited to your condition.

Never place on the head, eyes, mouth, neck, or across the chest/heart. Do not place over wounds, swollen areas, or suspected blood clots.

3 START LOW

Turn on at the lowest intensity. Select a program using the controls labeled on your unit. Increase gradually to a comfortable tingling sensation. Stimulation must not be painful. Do not reposition pads while the device is on.

USE & TROUBLESHOOT

Comfort and full contact matter

DURING & AFTER USE

Use for the duration recommended by your clinician and within the supplied device instructions. Turn off before adjusting, removing, or disconnecting pads. Stop immediately for burning, pain, dizziness, skin irritation, or other discomfort. Seek medical advice if symptoms persist or worsen.

NO POWER / NO STIMULATION

Check the battery or charge status and all connections. Confirm pads have full contact with clean, dry skin. With the unit off, reseal the connectors. Restart at the lowest intensity. Do not keep raising intensity to compensate for poor contact.

UNEVEN OR SHARP SENSATION

Turn off. Check for lifting, dry, worn, or damaged pads and replace as needed. Do not use a damaged unit or exposed wiring. If the problem continues, discontinue use and contact support.

BATTERY & DEVICE SAFETY

Follow battery polarity and type markings. Never recharge disposable batteries. Keep coin cells out of reach; suspected swallowing requires immediate medical attention. Do not open, modify, heat, or burn the unit. Dispose of electronics and batteries through local collection programs.